

Technical datasheet

Polymer Removal and Maintenance Solutions for the Spray Foam Market

TIPS TO ENSURE MAXIMUM PRODUCT EFFECTIVENESS:

Before using any Dynasolve™ product, refer to the product SDS for handling and safety information.

1. Follow the temperature guidelines provided
2. Agitation will improve product effectiveness (ultrasonic or mechanical)
3. Keep container loosely covered to prevent solvent loss

Application Requirement	Dynasolve Product	Specific Product Usage Guidelines
Removal of cured urethane buildup from spray foam equipment by soaking/immersion	Dynasolve™ CU-6	<ol style="list-style-type: none"> 1. Immerse part in Dynasolve CU-6 at room temperature. 2. Observe carefully. If urethane appears unaffected after 1 hour, heat solvent to 130° – 150°F (55° – 66°C). 3. If urethane appears unaffected after 2 hours, call technical support.
Removal of liquid isocyanate from system by flushing process	Dynasolve™ ISO-neutralizer	<ol style="list-style-type: none"> 1. Pour room-temperature Dynasolve ISO-neutralizer into isocyanate feed tank and circulate to mix with free isocyanate remaining in the system. 2. After 10–15 minutes of mixing, drain the mixture. 3. Now that the liquid isocyanate is removed from the system, the Dynasolve CU-6 product can be used to flush uncured material and remove crystallized isocyanate.
Removal of uncured urethane materials from system by flushing	Dynasolve™ CU-6	<ol style="list-style-type: none"> 1. After ensuring that liquid isocyanate has been removed from the system by utilizing Dynasolve ISO-neutralizer, introduce room-temperature Dynasolve CU-6 to the system to remove polyols, uncured urethane, and other urethane intermediates. 2. Mild heating of solvent will produce faster results.
Preparing spray equipment for long-term storage	Dyna-Lube	<ol style="list-style-type: none"> 1. After equipment has been flushed with Dynasolve CU-6, flush the unit with Dyna-Lube 1–3 times to remove the Dynasolve flushing solvent. 2. Pump Dyna-Lube into the system until it fills all areas of the unit. 3. Store unit, preferably in a cool, dry place. 4. When starting up unit, scrap the first few pounds of polyurethane sprayed through the machine to avoid adhesive failures.


www.emdgroup.com

Disclaimer

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. Customer is responsible for and must independently determine suitability of EMD's products for customer's products, intended use and processes, including the non-infringement of any third parties' intellectual property rights. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products: All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice.

The information on our trademarks is available in the Trademarks section on www.emdgroup.com. Detailed information on our trademarks are also available via publicly accessible resources. All other trademarks are the property of their respective owners.

© 2021 Merck KGaA, Darmstadt, Germany and/or its affiliates.



The Electronics business of Merck KGaA, Darmstadt, Germany operates as EMD Electronics in the U.S. and Canada.

Rev. (03/21)